

# PCMflash module 95

Toyota/Lexus Gen4


## Contents/Оглавление

|                          |   |
|--------------------------|---|
| Contents/Оглавление..... | 2 |
| M20A-FKS.....            | 3 |
| V24A-FTS/V35A-FTS.....   | 4 |

# PCMflash

Engine Control Unit

## M20A-FKS



|             |                |              |       |
|-------------|----------------|--------------|-------|
| <b>+12V</b> | T2: 21, 30, 31 | <b>CAN-L</b> | T2: 5 |
| <b>GND</b>  | T2: 22         | <b>CAN-H</b> | T2: 4 |

TOYOTA/LEXUS

pcmflash.ru

v.1


2023-12-24

# PCMflash

Engine Control Unit


## V24A-FTS/V35A-FTS

### T24A-FTS



|             |                   |              |        |
|-------------|-------------------|--------------|--------|
| <b>+12V</b> | T2: 12; T3: 8, 22 | <b>CAN-L</b> | T3: 25 |
| <b>GND</b>  | T3: 9             | <b>CAN-H</b> | T3: 26 |

### V35A-FTS



|             |               |              |        |
|-------------|---------------|--------------|--------|
| <b>+12V</b> | T2: 10; T3: 8 | <b>CAN-L</b> | T3: 17 |
| <b>GND</b>  | T3: 10        | <b>CAN-H</b> | T3: 18 |

TOYOTA/LEXUS

pcmflash.ru

v.2

2024-04-25